

Installation Instructions

SST5 and SST7 Speak-Thrus

SST5 SPEAK-THRU fits holes from 3" to 4-1/2" in diameter.

SST7 SPEAK-THRU fits holes from 4-1/2" to 6" in diameter.

1. Inspect contents of package. You should have one inner and one outer disc, with gaskets pre-installed, held together with 1/2" long screws. This will accommodate 1/4" thick glass. If you are using glass thicker than 1/4", use the optional 1-1/2" long screws (included). These screws will work on glass up to 1-1/4" thick. Simply cut the screws to accommodate your glass thickness. Glass thicker than 1-1/4" will require longer 8-32 flat head screws (not included).
2. Set outer disc from outside, centered over hole in glass. Line up inner disc from inside, and screw together. Before tightening screws, align slots in desired vertical or horizontal position.

